

Hose Type 6/4



Applications

Waterblasting: Heat Exchanger Tube Cleaning

Hydraulics: Bolt Tensioning and Torque Tools, Hydraulic Jacks, Controls for Service Equipment, Pressure Testing for Valves, Tooling and Control Panels, Instrumentation Packages for Gauges











Oil and Gas: Chemical Injection, Gaseous Media Handling, Grease Injection, Hydraulic Control, Nitrogen Service



Inner Core:	Polyoxymethylene (POM)
Pressure Support:	4 layers of high-tensile steel wire
Outer Cover:	Polyamide (PA)
Colour:	grey, other colours upon request
Temperature:	-22°F to 140°F [-30°C to +60°C]

Ø ID	Ø OD	Working Pressure*)	Burst Pressure ¹)	Min. Bend Radius	Weight	Nipple Ø ID	Sleeve	Sleeve Ø OD
0,25 inch	0,50 inch	21.750 psi	55.100 psi	7,09 inch	0,198 lbs/ft	0,14 inch	10640101 carbon steel	0,65 inch
6,3mm	12,6 mm	1.500 bar	3.800 bar	180 mm	0,295 kg/m	3,5 mm	10640105 AISI 316Ti	16,4 mm

Fittings: ID6, Series B and Y

Description	Size	Material	Part Number	
HP fitting	3/8"x24 UNF LH	AISI 316Ti	40640205B	
HP fitting BLAST PRO ²)	3/8"x24 UNF LH	stainless steel carbon steel	40640214Y sleeve / 10640232	
HP female BLAST PRO ²)	3/8"x24 UNF	stainless steel carbon steel	40640234Y sleeve / 10640232	
male fitting	1/4"x18 NPTF	carbon steel	30640401B	
male fitting with 60° cone	G1/4"	carbon steel	30640301B	
BSP female swivel	G1/4"	carbon steel carbon steel AISI 316Ti	20640301B swivel nut / 50540301 swivel nut /50540305	
metric female swivel with O-Ring	M18x1.5	carbon steel	20640241B / 50620201	
Type M female swivel	9/16"x18 UNF	carbon steel	20640641B / 50540601	
Type M female swivel	9/16"x18 UNF	AISI 316Ti	20640645B / 50540605	
JIC female swivel	9/16"x18 UNF	AISI 316Ti	20640655B / 50540605	

----- Additional fittings are available upon request. -----

¹) Production related variations up to 5 % are possible

²) BLAST PRO fittings must only be used for tube cleaning operation inside the tube. They are not designed for the use outside of tubes.

*) The safety factors between the burst pressure and the working pressure as well as the test pressure depend on the operating conditions. For gaseous media the outer cover is to be pinpricked. Regarding the safety factor for gaseous media please contact your local SPIR STAR® assembling center. The indicated working pressure refers to the hose only. Depending on the used fitting the permitted working pressure of a hose assembly can be less. We reserve our rights for changes without notice.

